PORTABLE 900MHz WIRELESS SPEAKER SYSTEM
EXPLODED VIEW (400-5029)
TRANSMITTER
FAXBACK DOC # 12933



Disassembly Instructions

1. Remove two screws 13 to disassemble the Back Panel.
2. Remove two screws 7 to disassemble the Front Cabinet.
3. Remove the black glue on the TX Antenna.
4. Remove one screw 21 to disassemble the TX Base PCB Panel.